


# Project Documentation

## Commodore PET/CBM80xx/40xx Diagnostic Keyboard PCB

Project number: 166

Revision: 0

Date: 27.10.2020



## Module Description

### Introduction

The Keyboard PCB is part of the Diagnostic Clip project. Originally, it was made with a connector and wires, but since PCBs got cheap and provide interconnects very reproduceable with a low failure rate, it is a very simple board design.




Figure 1: Pinout of the keyboard connector

KSCANx are the open collector outputs of a 74LS145 BCD to Decimal Decoder. So, it is not critical to connect more than one KeyScan Signal, nevertheless, the keyboard PCB provides diodes for a **wired-AND** connection, in case the slightly rare 74LS145 was replaced with another IC, that does not provide open collector outputs. The diodes could be replaced by a wire bridge.

Pins	Connected Signals
A-1-9	KIN0 - KeyScan0 - KeyScan8
B-2-10	KIN1 - KeyScan1 - KeyScan9
C-3	KIN2 - KeyScan2
D-4	KIN3 - KeyScan3
E-5	KIN4 - KeyScan4
F-6	KIN5 - KeyScan5
H-7	KIN6 - KeyScan6
J-8	KIN7 - KeyScan7





Figure 2: Dimensions of the Keyboard PCB

## Revision History


### Rev. 0

- Fully functional prototype




Title:	PET Diagnostic Keyboard PCB	Doc.-No.: 166-1-01-00
Date:	27.10.2020 15:17	Draft.: Sven Petersen
File:	PET_Diag_KB	Rev.: 0 Page 1/1
<a href="http://github.com/svenpetersen1965">http://github.com/svenpetersen1965</a>		
A4		


Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
placement component side		




Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
top		



Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
bottom		




Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
stopmask component side		






Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
stopmask solder side		



Sven Petersen 2020	Doc.-No.: 166-2-01-00	
	Cu: 35µm	Cu-Layers: 2
PET_Diag_KB		
04.01.2023 18:02		Rev.: 0
placement component side		measures



# Commodore PET Diagnostic Clip: Keyboard Dongle Rev. 0

## Bill of Material Rev. 0.0

Pos.	Qty	Value	Footprint	Ref.-No.	Comment
1	1	166-2-01-00	2 Layer	PCB Rev. 0	2 layer, Cu 35 $\mu$ , HASL, 53.0mm x 14.0mm, 1.6mm FR4
2	4	1N4148	DO-35	D1, D2, D3, D4	Diode 1N4148
3	1	BL1-85AXX-20U	BL1-85AXX-20U	J1	e.g. MPE Garry, Reichelt BL 1x20W8 2,54